

Fluid Port & Seal Kits

Bladder Kit


Bladder Assly & Anti-extrusion Kit

Anti-Extrusion Assly

Anti-extrusion ring, 'O' ring fluid port, back-up ring, sealed bleed valve (03 to 54L)


Fluid Port Assly

Body Fluid port, poppet valve assembly, flanged washer, locking ring, bleed valve assembly (03 to 54L)



Accumulator Reference	Oil Service Bladder Kit	Corrosion Service Bladder Kit	Oil Service Anti Ex'ing Assembly	Corrosion Service Anti Ex'ing Assembly	Oil Service Fluid Port Assembly	Corrosion Service Fluid Port Assembly
0B	0B00A-00	0B0SA-02	0B0**-00	0B0**-02	0B***-00	0B***-02
0F	0F00A-00	0F0SA-02	0F0**-00	0F0**-02	0F***-00	0F***-02
011	01100A-00	0110SA-02	0F0**-00	0F0**-02	0F***-00	0F***-02
01C	01C00A-00	01C0SA-02	0F0**-00	0F0**-02	0F***-00	0F***-02
030	03000A-00	0300SA-02	030**-00	0300**-02	030***-00	030***-02
03C	03C00A-00	03C0SA-02	030**R7	03C0**-02	03C***-00	03C***-02
04	0400A-00	0400SA-02	040**-00	040**-02	04***-00	04***-02
10	1000A-00	100SA-02	100**-00	100**-02	10***-00	10***-02
20	2000A-00	200SA-02	100**-00	100**-02	10***-00	10***-02
28	2800A-00	280SA-02	100**-00	100**-02	10***-00	10***-02
37	3700A-00	370SA-02	100**-00	100**-02	10***-00	10***-02
54	5400A-00	540SA-02	100**-00	100**-02	10***-00	10***-02

Other rubber material information available upon request.



Accumulator Reference	Gas Valve Core	Gas Valve Assembly	'O' Ring Fluid Port	Back-up Ring	Oil Service Locking Ring	Corrosion Service Locking Ring
0B	43001-099	N/A	40127-A00	40366-P00	24950-V29	24950-006
0F	43001-099	N/A	40294-A00	40367-P00	25010-V29	25010-006
01C	N/A	10053-S03	40294-A00	40367-P00	25010-V29	25010-006
03C	N/A	10053-S03	40306-A00	40875-P00	25060-V29	25060-006
04	N/A	10053-S03	40002-A00	40369-P00	25100-V29	25100-006
10-54	N/A	10053-S03	40003-A00	40370-P00	25150-V29	25150-006

Note: Gas valve assembly integral with bladder on OB to OF accumulators. Protective cap fitted on 01-54L accumulators only. NA = Not applicable. Bleed assembly fitted on 03-54L accumulators only.